

NO.	NAME	NO.	NAME
1	FRAME	67	MAG CATCH SP
2	SLIDE	68	VALVE KNOCKER SP
3-5	OUT BARREL	69	VALVE LOCK SP
4	HAMMER HOUSING	70	SLIDE STOP SP
5	MAIN SP HOUSING	71	SAFETY SP
6	TRIGGER HOUSING	72	RECOIL SP
7	SEAR	74	MAIN SP CAP
8	HAMMER	76	PISTON BLOCK SCREW
9	TRIGGER	77	MAG CATCH SP SCREW
10	TRIGGER BAR	78	BARREL CHAMBER SCREW
11	DISCONNECTOR	82	HAMMER PIN DETENT
12	SAFETY	83	MAG CATCH SP WASHER
13	SLIDE STOP	84	FRONT SIGHT
14	SAFETY DETENT PLUNGER	82	HAMMER PIN DETENT
15	PISTON BLOCK	83	MAG CATCH SP WASHER
18	TRAJECTORY ADJUST SCREW	84	FRONT SIGHT
19	FRONT RING	84-1	OPTICAL FIBER
20	MAGAZINE CATCH	86	MAIN SP HOUSING SLEEVE
21	MAIN SP STRUT	87	TRIGGER HOUSING PIN
22	RECOIL SP GUIDE	90	MAG BOTTOM STOP SCREW
23	VALVE HAMMER	92	CYLINDER SP
24	VALVE KNOCKER	93	TRAJECTORY ADJUST SCREW
25	VALVE LOCK PLATE	94	PISTON SCREW
29	TRAJECTORY ADJUST RING	95	INNER BARREL
30	GRIP (L)	96	CYLINDER
31	GRIP (R)	97	BARREL CHAMBER (L)
35	FLOATING VALVE	98	BARREL CHAMBER (R)
37	MAG BOTTOM	99	FLOATING VALVE
39	MAG GASKET	100	MAG LIP
41	PISTON RING	101	MAG BODY (CO2)
42	RECOIL BUFFER	102	MAG FOLLOWER
44	HAMMER PIN	103	FOLLOWER SP
45	HAMMER SLEEVE	104	CO2 EX VALVE
46	TRIGGER PIN	104-5	CO2 EX VALVE O-RING(BIG)
47	TRIGGER SLEEVE	105	MAG BOTTOM STOP
48	FLOATING VALVE PIN	106	RUBBER CHAMBER
49	DISCONNECTOR PIN	107	MAIN SP
50	VALVE KNOCKER PIN	109	PISTON BLOCK PLATE
51	VALVE KNOCKER SLEEVE	110	SAFETY RIGHT
52	VALVE HAMMER PIN	112	FRONT SIGHT PIN
53	BARREL LOCKING PIN	113	TRIGGER ADJUST SCREW
54	GRIP SCREW	140	REAR SIGHT BASE
55	MAIN SP HOUSING PIN	142	REAR SIGHT
56	SEAR PIN	143	REAR SIGHT ADJUST SCREW
57	MAG LIP PIN	144	REAR SIGHT SPRING
58	HAMMER SP GUIDE PIN	145	MAG CATCH PLATE
60	TRIGGER BAR PIN	154	REAR SIGHT PLATE
62	MAG STAB (CO2)	155	MAG CATCH PLATE SCREW
62-2	STAB O-RING	156	REAR SIGHT SCREW(EACH)
63	MAG BASE NUT (CO2)		
64	TRIGGER SP		
65	SEAR SP		
66	TRIGGER BAR SP		