



Fabric Universal Holster

- Release the thumb-break snap button and uncover the holster.
- Adjust the strap inside the holster to guarantee your weapon is in the proper position.
- Wrap the weapon and ensure to reserve the proper space of the holster with 2 velcro straps.
- Adjust the thumb-break strap.
- Practice holstering your weapon, and complete the adjustment.



Fabric Drop Leg Plate

- Attach the vertical strap to your belt, and adjust the length of the strap.
- Fasten the leg straps to adjust a comfortable length, firm but not too tight.
- Attach the holster to the drop leg plate, and practice holstering your weapon, and complete the adjustment.



AMOMAX Polymer Holsters Warranty

This policy applies to products purchased directly from Amomax. The proof of purchase will be required.

All Amomax Polymer Products carry the 1-year warranty against defects in materials and workmanship. This warranty does not cover damage to any Amomax product caused by ordinary wear and tear, intentional damage, misuse, abuse, neglect, improper storage, and use with incompatible firearms.

We will repair or replace the product and send it to you at the Company's expense.

Warm Tip

If you purchased your item from a dealer, please contact that dealer.

Cytac Technology Limited

- Address: 2nd Floor, Building D, 329 Donghuan Road, Xinqiao Street, Bao'an District, Shenzhen 518125, China
- Tel: +86-755-21502032
- Fax: +86-755-27804800
- Email: info@amomax.com