

LOADING MAGAZINE

FEEDING TUBE


LOADING ROD

- PLUG THE FEEDING TUBE BOTTOM END INTO THE BB EXIT SLOT OF THE MAGAZINE
- HOLD DOWN FEEDING TUBE FIRMLY AGAINST THE MAGAZINE
- DROP IN BB UNTIL TUBE IS FULL
- SLIDE LOADING RODE IN FEEDING TUBE
- PUSH DOWN BB INTO MAGAZINE

INSTALL/RELEASE MAGAZINE

- PLUG THE MAGAZINE INTO THE SLOT
- PUSH THE AMBIDEXTROUS LEVER TO RELEASE THE MAGAZINE

PRODUCT FEATURES



AST-01

SPECIFICATIONS

POWER SOURCE :	SPRING POWER
LENGTH :	1070mm
WEIGHT :	3000g
MAGAZINE CAPACITY :	55rounds
FIRE MODE :	SAFE / FIRE
MATERIAL :	Nylon Fiber + Metal
HOP-UP :	ADJUSTABLE

CHEEK PIECE ADJUSTMENT

1. LOOSE THE KNOBS
2. ADJUST THE CHEEK PIECE FOR YOUR OPTIMAL POSITION

LOADING OPERATION & LOAD INDICATOR

LOAD INDICATOR OFF AIRSOFT RIFLE NOT LOADED •

LOAD INDICATOR ON AIRSOFT RIFLE LOADED •

1. LIFT THE COCKING HANDLE UPWARD
2. HOLD THE HANDLE AND PULL ALL THE WAY BACK UNTIL IT STOPS (LOAD INDICATOR POP OUT)
3. PUSH FORWARD THE SPRING BOLT TO ITS ORIGINAL POSITION
4. PULL THE COCKING HANDLE BACK DOWN

BUTT PAD ADJUSTMENT

1. LOOSE THE KNOBS WITH TOOL
2. ADJUST THE BUTT PAD FOR YOUR OPTIMAL POSITION

TRIGGER ADJUSTMENT

1. LOOSE THE SCREW WITH HEX KEY
2. ADJUST THE POSITION AND FIX IT

SWITCH FIRE MODE

SAFE MODE:

- PULL THE SAFETY LEVER BACKWARD

FIRE MODE:

- PUSH THE SAFETY LEVER FORWARD

TO SHOOT

- PULL THE TRIGGER TO SHOOT

HOP-UP ADJUSTMENT

- USE A HEX KEY TO ADJUST HOP-UP
- DIAL CLOCKWISE FOR MORE HOP-UP
- DIAL COUNTER-CLOCKWISE FOR LESS HOP-UP (HEX KEYS ARE INCLUDED INSIDE PISTOL GRIP)

SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE!

FOR ADULT USE ONLY. NOT TO BE OPERATED BY MINORS UNDER THE AGE OF 18.

NEVER MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in any way could make your airsoft gun unsafe to use, cause serious injury or death, and will void the warranty.

Misuse of Airsoft Guns is dangerous and can cause serious injury or death. Always treat an Airsoft gun with the same respect you would towards a real firearm.

SAFETY CONSIDERATIONS

- NEVER look into the gun's muzzle.
- NEVER point the Airsoft gun at anything you do not intend to shoot.
- NEVER shoot at targets that may cause the BB to bounce off, such as hard surface that could produce a ricochet.
- ALWAYS ensure the operator and everyone nearby are wearing appropriate eye protection.
- ALWAYS ensure the fire-selector is on "SAFE" until you are ready to shoot.
- ONLY shoot the airsoft gun in designated area, towards a safe direction, using a sufficient backstop.

GENERAL PRECAUTIONS

- This merchandise does not contain any internal components compatible or interchangeable with a real firearm.
- This merchandise cannot accept firing components from a real firearm, nor be able to chamber / fire real ammunition.
- This merchandise is designed to function solely with 6mm airsoft ammunition. ONLY use high-quality precision plastic BBs designed for 6mm Airsoft guns.
- NEVER reuse a BB that is dirty, has been shot from the gun, or otherwise deformed.
- Use of contaminated or imperfect BBs could damage your gun.
- ALWAYS transport Airsoft guns in its original box or an appropriate gun case.
- NEVER carry the gun in plain sight.
- ALWAYS store the airsoft gun unloaded, and out of reach by children.
- Using unauthorized repair centers or modifying the function of your airsoft gun in any way may be unsafe and will void your warranty.
- The manufacturer, distributors, and retailers are not liable for any malfunction, accidents, injuries or repair cost resulting from misuse, or by disassembly and modification of the airsoft gun.

CAUTION

WARNING

AMOEBA

Divisions of Forever Good (Hong Kong) Ltd.

ARES AX Octarms SP SUPER-LET SHOOTER GIGERS

FOR GENERAL ENQUIRY, CONTACT US AT
ARES@ARES-AIRSOFT.COM
 FOR THE LATEST NEWS AND PRODUCT INFORMATION, VISIT US AT
WWW.AMOEBA-AIRSOFT.COM
WWW.ARES-AIRSOFT.COM
f AIRSOFTAMOEBA

