

E&C ADVANCED 150 m/s

HOW TO SET UP E.T.U.



The gun is equipped with a E.T.U. (Electronic Trigger Unit) with a trigger microswitch, mosfet, active brake, magnetic sensor and allows you to set 5 different shooting modes. Follow the steps below to change the mode.

- 1) Switch selector lever to the SEMI position.
- 2) Press and hold the trigger until the engine vibrates - enter programming mode.
- 3) Pressing the trigger you are switching between the modes - 5 predefined modes (see the table).
 1. vibration signals the number of shots in SEMI, 2. vibration signals the number of shots in AUTO.
- 4) Switching the selector lever to AUTO saves the selected mode.

E.T.U. remembers the last set mode after disconnecting the battery. Follow the steps above to change the mode. Maximum voltage 16 V and current 50 A.

SHOOTING MODES

MODE	SEMI	AUTO
1.	1 shot	FULL
2.	1 shot	3 shots
3.	3 shots	FULL
4.	1 shot	1 shot
5.	3 shots	3 shots

UPGRADE INNER PARTS



E.T.U. with microswitch • Aluminium nozzle with double sealing • Metal cylinder head with double sealing • Chrome polished cylinder • Metal piston head • Polymer piston with metal teeth • Metal spring guide with bearing • Reinforced gear set 18:1 • ProWin style hop-up chamber