


NEBULA 2

BUILT-IN ELECTRONIC TRIGGER UNIT

QUICK START GUIDE

ENTER PROGRAM MODE



TURN THE SELECTOR TWICE FROM AUTO TO SEMI, AND ENTER THE PROGRAM SELECTION IN "SEMI" MODE. LONG PRESS THE TRIGGER UNDER "AUTO" MODE FOR THREE SECONDS TO SAVE THE PROGRAM.



PROGRAM CONFIGURATION

→ 1X - AUTO FIRE MODE	→	1x - AUTO ↓ 2x - SEMI ↓ 3x - 3 RD BURST ↓ 4x - 5 RD BURST	► 3 • ► 3 .. ► 3 ... ► 3
↓			
2X - SEMI FIRE MODE	→	1x - SEMI ONLY ↓ 2x - BINARY ↓ 3x - AUG ↓ 4x - SNIPER	► 3 • ► 3 .. ► 3 ... ► 3
↓			
3X - TRIGGER MODE	→	1x - 20% ↓ 2x - 40% ↓ 3x - 60% ↓ 4x - 80% ↓ 5x - 100%	► 3 • ► 3 .. ► 3 ... ► 3 ► 3
↓			
4X - PRE-COCKING	→	1x - LEVEL 1 ↓ 2x - LEVEL 2 ↓ 3x - LEVEL 3 ↓ 4x - LEVEL 4 ↓ 5x - LEVEL 5 ↓ 6x - LEVEL 6	► 3 • ► 3 .. ► 3 ... ► 3 ► 3
↓			
5X - ACTIVE BRAKE	→	1x - ON ↓ 2x - OFF	► 3 • ► 3 ..