


WE GALAXY G-SERIES CNC HOP UP CHAMBER

安裝說明 INSTALLATION MANUAL




| NO. | 品名 Parts name | NO. | 品名 Parts name |
|-----|----------------------|-----|--|
| 1 | 內腔座/Hop-up chamber | 8 | 套管/Barrel spacer |
| 2 | 插梢/Pin | 9 | 前管/Front barrel |
| 3 | 彈簧A/Spring A | 10 | 定位柱/Knob detent |
| 4 | 橡膠圓柱/Hop-up nub | 11 | 彈簧B/Spring B |
| 5 | 壓桿/Hop-up lever | 12 | 半圓頭內六角M3X4 X2 Hex socket head cap M3X4 X2 |
| 6 | O環/O-ring | 13 | 止付M3X5 X3 Set screws M3X5 X3 |
| 7 | 調整輪/Adjustment whell | | |


1. 安裝O環,內腔橡皮,內管
1. Insert the O-ring and inner barrel & hop up bucking into chamber.



2. 安裝彈簧A,橡膠圓柱
2. Insert the spring A, Hop-up nub.



3. 安裝調整輪,外管,套管
3. Insert the adjustment whell, out barrel, barrel spacer.



4. 彈簧調整
4. HOP-UP ADJUSTMENT

