

# P★M

BLOWBACK ★ 6 mm (0.24)  
PLASTIC  
BBS  
AIR SOFT



CO2 Cartridge is not included  
12g  
MADE IN TAIWAN

## AAKCCB44 系說明書 AAKCCB44 INSTRUCTION MANUAL

**KWT** KWIEN WELL TOY INDUSTRIAL CO., LTD  
www.kwcgun.com

台南市仁德區義林路168巷89號  
NO.89, LN. 168, YILIN RD.,  
RENDE DIST., TAINAN CITY  
71752, TAIWAN (R.O.C.)  
TEL : +886-6-2798175  
FAX: +886-6-2798176  
sales@kwcgun.com  
www.kwcgun.com



## 操作/OPERATION

### 操作說明

#### OPERATION

1. 取出彈匣  
RELEASE MAGAZINE




▲注意：請勿使彈匣直接掉落地面，以防止變形或損壞。

▲CAUTION: Magazine falling directly on the ground could cause deform or damage on it. Please be aware.

2. CO2小鋼瓶12g的使用  
INSTALLING 12G CO2 CARTRIDGE

逆時針轉出彈匣底內件後，置入小鋼瓶B，再以順時針方向鎖緊彈匣底內件A。當刺破鋼瓶出氣時，請快速鎖緊。  
Turn the magazine cap out counter-clockwise and place CO2 cartridge B inside the magazine. Rapidly turn the screw A clockwise when piercing the cartridge in the magazine.



▲注意：為維護彈匣使用壽命，請盡可能不要殘留CO2氣體於彈匣內。

▲CAUTION: To protect your magazine, please release all of the CO2 out of the magazine after every use.

3. 填裝BB彈  
LOADING BBS

為了使擊發順暢，填裝方法是讓B.B彈在彈匣中一粒接著一粒。  
For smooth shooting, Load BBs one by one.

▲注意：彈匣最多可裝15發B.B彈，如強行裝入更多，可能造成不當損壞及無法上膛，請注意。

▲CAUTION: Magazine max capacity is 15 rounds. Loading more than this quantity could bring malfunctions.

4. 彈匣上膛  
INSERTING THE MAGAZINE

將裝好BB彈的彈匣插入槍身上推入，直到彈匣卡筭發出"卡嗒"為止。  
Insert fully loaded magazine in the airsoft until you hear the sound of "CLICK".

5. B.B彈上膛  
CHAMBERING THE BB

將上蓋往後拉到底，放開上蓋則上蓋會自動回位，同時亦將B.B彈送上膛完成射擊準備。  
Pulling the slide back. When the slide has been pulled completely back, release the slide without pushing and the BBs will be chambered.



▲注意：拉動上蓋時，請勿將手指扣住扳機，以免發生不當射擊，造成危險。

▲CAUTION: The gun is now cocked and will fire when the trigger is pulled. Be careful not to fire accidentally.

6. 保險切換  
SWITCH SAFETY



▲注意：在保險開啟時上蓋無法推動  
▲CAUTION: When safety is on, slide can not be moved.



▲注意：上蓋滑動時，注意縫隙夾到手指  
▲CAUTION: This airsoft has a realistic blowback feature. Be careful of the pinch point.

7. 射擊  
SHOOTING

對準目標區後扣下扳機，則B.B彈將被射擊出去。  
Aim the target and pull the trigger. Then the BB will be shot.




▲注意：B.B彈用完時，上蓋會後定卡住。  
▲CAUTION: hold open function as real pistol.

### 拆解/DIS-ASSEMBLY

1. 拆解前退下彈匣  
Remove the magazine before disassemble.  
2. 先將護弓往下拉開  
Pull down the trigger guard.



3. 固定住護弓後再向後推出滑蓋，再往上拉起上蓋即可拆解分離  
Hold the trigger guard and pull back the slide. To remove slide, simply pull up the slide.



4. 上蓋拆解分離完成  
Slide disassembly done.



▲注意：裝入導管壓簧時，裝入方向如圖所示。  
▲CAUTION: When inserting the outer barrel spring, mind the direction as shown above.

5. HOP UP調整  
Adjust HOP UP system.



### 故障的原因與排除 BREAK DOWN FAQ

- \* 卡彈可能原因：  
the reason for BB jam :  
a. 裝彈排列不整齊  
the BB in the magazine does not arrange very well.  
b. 不良B.B彈  
bad quality BB



\* 排除：將上蓋往後拉，向下倒出即可。  
Solution: pull the slide back and pour the BB out from slide.






\* 射擊過程中偶而會發生，在作動時上蓋突然停止無法作動，而擊鐵回到原位，彈匣中仍有足夠瓦斯和BB彈。  
During the shooting process, sometimes the Slide and the Hammer stop unexpectedly.



\* 排除：此時並非故障，只需重新上膛便可繼續使用。  
Solution: This is not a failure. Just reload and operate again.

### \* 保養及維護 MAINTENANCE GUIDE

當射擊約2000發時，建議你如圖所示，以矽油脂適當在上蓋與本體滑動接觸面及擊鐵、撞針作動處潤滑，以利滑動。  
After every 2,000 BB shots, lubricating the Firing pin and Track as pictures below is recommended.



# WARNING 警告

## 請務必嚴格遵守 使用說明指導書

For your safety, please read this manual carefully before use.


此低動能遊戲用槍是針對喜愛射擊運動的消費者所開發。避免因使用方法不正確或改造所發生的故障或事故，請務必詳讀說明書，正確的操作享受愉快的射擊運動。

- 除了發射時外，不要將手指頭掛在板機上。
- 選擇安全與適當標靶
- 在非使用期間，請保持保險關閉且退彈的狀態，就算在非使用狀態，也要如同其已裝彈。
- 如任何的機械產品，槍的保險也可能失效。即使在保險關閉的狀態下也請小心的操作此槍，請勿將槍口對人。
- 千萬不要對堅硬或平坦表面、水面射擊，以避免跳彈。
- 請妥善保管產品在未成年孩童無法伸手取得的場所。
- 每次使用前後都應該檢查擋彈物，假如擋彈物表面有磨損失效或是反彈時請停止使用。
- 請使用高品質BB彈，請勿使用①口徑大於6mm②表面不平滑的③重複使用過的BB彈④非本說明書指定的發射物。
- 最高的使用及儲藏CO2小鋼瓶環境為50°C(122°F)以內，高溫可能會造成CO2小鋼瓶過熱甚至爆炸。
- 檢查任何掉落之槍枝，以確保未影響其功能。


**This airsoft is intended for recreational or training purposes. To prevent improper handling, modification or alteration causing malfunction or accident, please read the owner's manual carefully. Enjoy the pleasant shooting experience by proper operation.**

- Do not put your finger on the trigger except shooting.
- Please choose safe and proper target.
- Please always keep the airsoft on safe and unloaded when not using.
- Like all mechanical devices, an airsoft safety can fail. Always handle the airsoft safely even when the safety is "on safe". Never point the airsoft at any people.
- Avoid ricochet. Never shoot at a hard or flat surface or at water.
- Keep the airsoft out of reach for small children.
- Your backstop should be inspected for wear before and after each use. Discontinue use of the backstop if surface shows signs of failure or ricochet.
- Only use high quality BB. Never use ①BB diameter larger than 6mm②BB with unsmoothed surface③reused BB that has been fired④incorrect projectiles not design for this airsoft
- Do not expose CO2 cartridges to heat or store them at temperatures above 50°C(122°F). CO2 cartridges may over heat or explode at temperatures above 50°C(122°F).
- Check any gun that has been dropped to ensure that its function has not been affected.


★使用低動能遊戲用槍前，請務必戴上保護眼鏡或面罩。



★不可攜帶低動能遊戲用槍在公共場所行走，請務必裝在袋子或盒子內。




★使用低動能遊戲用槍前，請務必詳讀說明書內容。




★請不要由槍口向內探視。




★請不要在公開場合使用低動能遊戲用槍，也請不要拿低動能遊戲用槍對準人或動物。



★請確認後再發射BB彈方向，附近無人或動物存在。



★不可任意改造或加工低動能遊戲用槍，私自改造加工會造成產品損壞、保固失效，導致使用上不安全，甚至觸法送辦。




Do not display this pistol in public—it may confuse people and may be a crime. 請不要忘了，雖然自己知道這只是玩具，但不知道的人，會以為這是真槍。

# AAKCCB44 系列 零件表 AAKCCB44 SERIES PARTS LIST

NO.	零件名稱	UNIT	NO.	零件名稱	UNIT	NO.	零件名稱	UNIT
P03	滑套射嘴	LOADING NOZZLE	R01	氣嘴迫緊	GAS ROUTE PACKING	S01	擊鐵壓簧	HAMMER SPRING
P05	彈匣上部	MAGAZINE RIB	R04	子彈迫緊HOP-UP	RUBBER CHAMBER	S02	撞針扭簧	FIRING PIN SPRING
P06	彈匣滑粒	MAGAZINE FOLLOWER				S03	彈匣卡榫扭簧	MAGAZINE CATCH SPRING
P07	彈匣底座配件	MAGAZINE BASE ACCESSORY	G008	O形環 1X6id(NBR)	O-RING 1X6id(NBR)	S05	擊鐵卡榫扭簧	HAMMER CATCH SPRING
P23	槍柄	GRIP	G016	O形環 S-4(PU90)	O-RING S-4(PU90)	S06	止動片扭簧	SLIDE STOPPER SPRING
KMB44-P34	氣流控制件	FLOATING VALVE	G022	O形環 S-8(NBR)	O-RING S-8(NBR)	S07	扳機連桿右扭簧	TRIGGER BAR RIGHT SPRING
KMB07-P41	心棒迫緊	VALVE PACKING	G034	O形環 P-9(PU90)	O-RING P-9(PU90)	S08	氣流控制件壓簧	FLOATING VALVE SPRING
						S09	保險扭簧	SAFETY SPRING
A02	上蓋	SLIDE	B03	護弓軸	TRIGGER GUARD PIN	S10	槍柄扣環	GRIP BUCKLE
			B04	扳機連桿軸	TRIGGER BAR AXLE	KCB76-S10	撞針卡榫壓簧	FIRING PIN CATCH SPRING
Z01	本體	FRAME	B05	彈匣上部軸	MAGAZINE RIB PIN	S11	導管壓簧	RECOIL SPRING
Z03	扳機	TRIGGER	B07	氣閥本體	VALVE FRAME	S12	護弓壓件壓簧	TRIGGER GUARD PRESS SPRING
Z04	擊鐵卡榫	HAMMER CATCH	B08	心棒後部	VALVE REAR	S13	射嘴回位壓簧	LOADING NOZZLE RECOIL SPRING
Z05	撞針卡榫	FIRING PIN CATCH	B10	內槍管	INNER BARREL	S15	彈匣壓簧	MAGAZINE SPRING
Z06	保險左	SAFETY(L)	B12	護弓壓件	TRIGGER GUARD PRESS UNIT	S16	心棒壓簧	VALVE SPRING
Z07	擊鐵箱右蓋	CHASSIS(R)	B13	扳機軸	TRIGGER PIN	S17	扳機扭簧	TRIGGER SPRING
Z08	彈匣本體	MAGAZINE FRAME	B14	彈匣卡榫軸	MAGAZINE CATCH PIN	EA021	螺絲 Φ2.3X6(束黑熟)	SCREW 2.3X6
Z09	擊鐵	HAMMER	B15	導管固定軸A	BARREL FIXTURE A	EA045	螺絲 ΦM3X8XP0.5 耐落	SCREW M3X8XP0.5
Z11	護弓	TRIGGER GUARD	B16	擊鐵軸套	HAMMER SLEEVE	EA061	螺絲 Φ2.3X5(束黑熟)	SCREW 2.3X5
Z12	彈匣卡榫	MAGAZINE CATCH	B18	導管固定軸B	ABARREL FIXTURE B	EA066	螺絲 Φ2.3X8(束黑熟)	SCREW 2.3X8
Z15	BAX調整圈	BAX ADJUST RING	B19	擊鐵箱軸	CHASSIS PIN	EA078	ΦM3.0X12黑	SCREW M3.0X12
Z16	BAX調整件B	BAX ADJUST PLATE	B20	擊鐵軸	HAMMER PIN	EA087	內六角螺絲	SOCKET SCREW
Z20	氣缸	CYLINDER	B21	止動片固定軸	SLIDE STOPPER FIXTURE PIN	EA112	內六角止付螺絲	MAGAZINE BOTTOM CAP
Z24	撞針	FIRING PIN	B22	連桿扭簧固定軸套	TRIGGER BAR SPRING FIXTURE SLEEVE	EB002	彈簧墊圈	SPRING WASHER
Z25	擊鐵箱左蓋	CHASSIS(L)	B23	活塞	PISTON	KCB76-E08	內六角止付螺絲	MAGAZINE BOTTOM CAP
Z26	擊鐵箱中蓋	CHASSIS(C)	B24	擊鐵導桿軸	HAMMER STRUT PIN			
Z28	槍管右蓋	INNER BARREL CASE(R)	B26	擊鐵卡榫軸套	HAMMER CATCH PIN SLEEVE	X1	氣缸組件	CYLINDER UNIT
Z29	槍管左蓋	INNER BARREL CASE(L)	B27	射嘴壓簧導軸	NOZZLE SPRING GUIDE PIN	U1	內槍管組件	INNER BARREL UNIT
			B31	氣瓶頂針	PUNCTURE VALVE	U2	擊鐵箱組件	HAMMER CASE UNIT
F01	擊鐵導桿	HAMMER STRUT	KC15-B33	心棒	VALVE	U3	氣閥組件	VALVE UNIT
F02	扳機連桿	TRIGGER BAR	KMB44-B34	外槍管	OUTER BARREL	U4	氣瓶頂針組件	PUNCTURE VALVE UNIT
F03	上蓋止動片	SLIDE STOPPER	KG12-B215	氣瓶頂針迫緊	PUNCTURE VALVE PACKING			

# AAKCCB44 系列 零件分解圖 AAKCCB44 SERIES EXPLODED VIEW



※零件有時為了改良而不經預告變更。  
Spare parts may be modified for quality improvement  
And such modification may be without advance notice.